

Terminal	Terminal Software ≥ ...	AXIS-H 30.x EMC (W) AXIS-H 50.x EMC W < serial no. 09-050000 TeeJet-Controller IC18	AXIS M 20.2/30.2 EMC+W NG AXIS M 50.2 EMC+W NG AXIS H 30.2 EMC+W NG AXIS H 50.2 EMC+W NG ≥ serial no. 09-050000 with SpeedServos AXENT 100.1 (remains at V4.11.00) ≥ S/N 08-010103 with SpeedServos Eckelmann-Controller (NG)	AGT 6030 AGT 6032 AGT 6036 Müller-Controller	AERO GT 60.1 Eckelmann-Controller
		Software job computer			
		V4.12.00	V5.00.00	V2.50.00 V2.50.02	V1.10.00
CCI 50 100 200 	V0000.05.60.01 HW 2.xx	UT (2x6) TC-BAS, TC-GEO, TC-SC T-ECU AUX-N GPS-V Opti	UT (2x6) TC-BAS, TC-GEO, TC-SC T-ECU AUX-N GPS-V Opti	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N	
CCI 1200 800 	V1.1.7 CCI 800 from V2.0.2	UT (2x6) TC-BAS, TC-GEO, TC-SC T-ECU AUX-N GPS-V Opti Control points	UT (2x6) TC-BAS, TC-GEO, TC-SC T-ECU AUX-N GPS-V Opti Control points	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N	UT (2x6) TC-BAS, TC-GEO, TC-SC T-ECU AUX-N GPS-V Control points
Müller-Elektronik Comfort Basic Top 	V4.10.05	UT (2x5) TC-BAS, TC-GEO, TC-SC T-ECU ¹ AUX-N GPS-V Opti	Only with HW > 3: UT (2x5) TC-BAS, TC-GEO, TC-SC T-ECU ¹ AUX-N GPS-V Opti	UT (2x5) TC-BAS, TC-GEO, TC-SC AUX-N	
Müller-Elektronik Touch 800 1200 	V2.20.11	UT (2x6) TC-BAS, TC-GEO, TC-SC T-ECU AUX-N GPS-V Opti	UT (2x6) TC-BAS, TC-GEO, TC-SC T-ECU AUX-N GPS-V Opti Control points	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N
John Deere GS 2630 	V3.34.1345	UT (2x5) TC-BAS, TC-GEO, TC-SC AUX-N GPS-V Control points	UT (2x5) TC-BAS, TC-GEO, TC-SC AUX-N GPS-V Control points (only 16 sections)	UT (2x5) TC-BAS, TC-GEO, TC-SC AUX-N (only compatible with SW 2.50.00)	
John Deere GS 4640/4240 	GS 4640: V10.13.909-178 GS 4240: V10.19.1893-81	UT (2x6) TC-BAS, TC-SC AUX-N GPS-V	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N GPS-V Opti Control points	UT (2x6)	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N GPS-V Control points
Kverneland Tellus Pro ISOMatch 	V1.06.1.4	UT (2x5) TC-BAS, TC-GEO, TC-SC T-ECU AUX-N	UT (2x5) TC-BAS, TC-GEO, TC-SC ⁵ T-ECU AUX-N		
Kverneland Tellus GO 	V1.05.05		UT (2x5) TC-BAS, TC-GEO, TC-SC T-ECU AUX-N		
Fendt Touch NT 10,4" 	V7.81	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N Opti	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N ⁶ Opti (only 36 sections)	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N
Fendt One 		UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N Opti	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N ⁶ Opti		

Terminal	Terminal Software ≥ ...	AXIS-H 30.x ISOBUS AXIS-H 50.x ISOBUS < serial no. 09-050000 TeeJet-Controller	AXIS M 20.2/30.2 EMC+W NG AXIS M 50.2 EMC+W NG AXIS H 30.2 EMC+W NG AXIS H 50.2 EMC+W NG ≥ serial no. 09-050000 with SpeedServos AXENT 100.1 ≥ serial no. 08-010103 with SpeedServos Eckelmann-Controller (NG)	AGT 6030 AGT 6032 AGT 6036 Müller-Controller	
		Software job computer			
		V4.12.00	V5.00.00	V2.50.00 V2.50.02	
Trimble TMX IQ Field 	V5.60	UT (2x6) TC-GEO, TC-SC AUX-N Opti Control points	UT (2x6) TC-GEO, TC-SC AUX-N GPS-V Opti Control points	UT (2x6) TC-SC AUX-N	
Trimble GFX 750 	V1.60	UT (2x6) TC-GEO, TC-SC AUX-N Opti Control points	UT (2x6) TC-GEO, TC-SC AUX-N GPS-V Opti Control points		
Raven CR12 			UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N		
Valtra Smart Touch 			UT (2x6) TC-BAS, TC-SC AUX-N		
AG Leader In Command 1200 	V3.5	UT (2x5) TC-BAS, TC-GEO, TC-SC	UT (2x6) TC-BAS, TC-GEO, TC-SC	UT (2x6) TC-BAS, TC-GEO, TC-SC	
Claas S10 ⁴⁾ 	V4.00.04	UT (2x5)	UT (2x5) TC-BAS, TC-GEO, TC-SC AUX N (only 32 sections)		
TopCon Horizon X Series SameDeutzFahr iMonitor2 	V4.02.24	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N Opti	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N Opti Control points	UT (2x6) TC-BAS, TC-GEO, TC-SC	
CNH IntelliView IV AFS pro 700/1200 	V31.12	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N Opti		
MF Fieldstar 5 	V3.3		UT (2x5) TC-BAS, TC-GEO, TC-SC AUX-N		
TeeJet Aeros 	V4.33		UT (2x5) TC-BAS, TC-GEO, TC-SC Opti (only 30 sections)		
Amazone AmaTron 4 	NW216-C.008		UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N Opti		

UT	Universal terminal = handling only using the buttons; details in brackets = number of buttons
TC-BAS	Task Controller Basic = documentation of output data in ISO-XML format
TC-GEO	Task Controller Geo = documentation of stationary data, application cards in ISO-XML format
TC-SC	Task Controller Section Control = automatic section control and headland switch, OptiPoint including
T-ECU	Tractor ECU = provision of the speed signal to the terminal, connection to the 7-pin signal socket
GPS-V	Use of the GPS-speed of the ISOBUS terminal is possible
AUX-N	Auxiliary Control (new) = additional control units like joystick
Opti	Automatic transmission of the OptiPoint values of the fertiliser spreader to the SC settings of the terminal. If no, the OptiPoint works nevertheless, but you have to enter the values manually
Control Points	2 required rates per working width (spreading of application cards)

- 1) From HW 3.00.00, cable 2057692 necessary
- 2) Only in connection with active TC-BAS/TC-GEO
- 3) After a transfer the accessory equipment has to log-in again
- 4) TC-BAS,TC-SC only with deactivated telemetry function
- 5) The distance x must be transferred manually from the OptiPoint
- 6) FendtOne AUX-N won't work with AXENT V4.11.00 yet

All information is supplied without guarantee. Changes reserved. Current lists you can always find on the Internet at www.rauch.de or www.aef-database.org