

Terminal	Terminal Software ≥ ...	AXIS M 20.2/30.2 EMC+W NG AXIS M 50.2 EMC+W NG AXIS H 30.2 EMC+W NG AXIS H 50.2 EMC+W NG ≥ S/N 09-050000 with SpeedServos AXENT 90.1/100.1 ≥ S/N 08-010103 with SpeedServos Eckelmann-Controller (NG, G2.5)	AERO GT 60.1 (Multirate)⁴ AERO 32.1 (Multirate)⁴ Eckelmann-Controller (NG)
		Software Jobcomputer	
		V6.00.00	V3.00.00
CCI 50 100 200 	V0000.05.60.01 HW 2.xx	UT (2x6) TC-BAS, TC-SC T-ECU GPS-V Opti	
CCI 1200 800 	V4.0.4	UT (2x6) TC-BAS, TC-GEO, TC-SC T-ECU AUX-N GPS-V Opti 2 Control Points	UT (2x6) TC-BAS, TC-GEO, TC-SC T-ECU AUX-N GPS-V 30 delay times 30 Control Points
Müller-Elektronik Touch 800 1200 	V2.30.08	UT (2x6) TC-BAS, TC-GEO, TC-SC T-ECU AUX-N GPS-V Opti 2 Control Points	UT (2x6) TC-BAS, TC-GEO, TC-SC TECU AUX-N GPS-V
John Deere GS 4640/4240 	V10.28.3314-79	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N Opti 2 Control Points	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N 1 delay time 2 Control Points
John Deere G5 	V10.28.3314-79	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N ⁵ Opti 2 Control Points	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N 1 delay time 30 Control Points
Kverneland Tellus Pro ISOMatch 	V1.9.0.11	UT (2x5) TC-BAS, TC-GEO, TC-SC ¹⁾ T-ECU GPS-V AUX-N Opti ²⁾	UT (2x5) TC-SC GPS-V AUX-N
Kverneland Tellus GO 	V1.05.5	UT (2x5) TC-BAS, TC-GEO, TC-SC ¹⁾ T-ECU AUX-N Opti ²⁾ (max. 24 Sections)	
Fendt One 	F08.000.22.000014	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N GPS-V Opti 2 Control Points	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N 30 delay times 30 Control Points
Trimble TMX IQ Field 	V11.27	UT (2x6) TC-GEO, TC-SC AUX-N GPS-V Opti 2 Control Points	UT (2x6) TC-GEO, TC-SC AUX-N GPS-V 1 delay time 30 Control Points
Trimble TME/GFX 1060 	V14.40	UT (2x6) TC-GEO, TC-SC AUX-N GPS-V Opti 2 Control Points	UT (2x6) TC-GEO, TC-SC AUX-N GPS-V 1 delay time 30 Control Points

Terminal	Terminal Software ≥ ...	AXIS M 20.2/30.2 EMC+W NG AXIS M 50.2 EMC+W NG AXIS H 30.2 EMC+W NG AXIS H 50.2 EMC+W NG ≥ S/N 09-050000 with SpeedServos AXENT 90.1/100.1 ≥ S/N 08-010103 with SpeedServos Eckelmann-Controller (NG, G2.5)	AERO GT 60.1 (Multirate)⁴ AERO 32.1 (Multirate)⁴ Eckelmann-Controller (NG)
		Software Jobcomputer	
		V6.00.00	V3.00.00
Raven CR12 	23.4.2.19	UT (2x6) TC-GEO, TC-SC AUX-N GPS-V 2 Control Points	UT(2x6) TC-BAS, TC-GEO, TC-SC AUX-N GPS-V 2 Control Points
Valtra Smart Touch 		UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N Opti 2 Control Points	UT (2x6) TC-BAS, TC-GEO, TC-SC
AG Leader In Command 1200 	V9.5	UT (2x5) TC-BAS, TC-GEO, TC-SC AUX-N GPS-V	UT (2x5) TC-BAS, TC-GEO, TC-SC AUX-N GPS-V
Claas Cemis 1200 	V2.3	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N GPS-V Opti 2 Control Points	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N 30 delay times 30 Control Points
TopCon X35 	V5.03.39	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N Opti 2 Control Points	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N 1 delay time 30 Control Points
CNH IntelliView IV AFS pro 700 Plus 	V38.1	UT (2x6)	UT (2x6)
IntelliView 12 AFS Pro 1200 	V4.33	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N Opti 2 Control Points	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N 6 delay times 6 Control Points
MF Fieldstar 5 		UT (2x6)	UT (2x6)
Amazone AmaTron 4 	NW216-I.036	UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N GPS-V Opti 2 Control Points	UT(2x6) TC-BAS, TC-GEO, TC-SC AUX-N GPS-V 30 delay times 30 Control Points
Fendt Touch NT 10,4“ 	V7.81	(tested up to SW 5.31.00) UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N Opti (only 36 sections)	(tested up to SW 2.10.00) UT (2x6) TC-BAS, TC-GEO, TC-SC AUX-N 6 delay times
John Deere GS 2630 	V3.34.1345	(tested up to SW 5.10.00) UT (2x5) TC-BAS, TC-GEO, TC-SC AUX-N GPS-V 2 Control Points (only 36 sections)	
Claas S10 ³ 	V4.00.04	(tested up to SW 5.10.00) UT (2x5) TC-BAS, TC-GEO, TC-SC AUX N (only 36 sections)	

UT	universal terminal = handling only using the keys; details in brackets = number of keys
TC-BAS	Task Controller Basic = documentation of output data in ISO-XML forma
TC-GEO	Task Controller Geo = documentation of stationary data, application card in ISO-XML format
TC-SC	Task Controller Section Control = automatic section control and headland circuit, OptiPoint inclusive
T-ECU	Tractor ECU = Provision of the speed signal to the terminal, connection to the 7-pin signal socket
GPS-V	Use of the GPS-speed of the ISOBUS terminal is possible
AUX-N	Auxiliary Control NEW Auxiliary Control Old = additional controls e.g. joystick
Opti	Automatic transmission of the OptiPoint-values of the spreader to the SC settings of the terminal. If no, the OptiPoint works nevertheless, you have only to enter the values manually
Control Points	2 required rates per working width (spreading of application cards)
delay times	Possible delay times of single sections, which are supported from the Terminal. Important, because each dosing works with an other time.

- 1) The distance x must be transferred manually from the OptiPoint
- 2) Delay times are only transferred to the terminal after restarting the spreader
- 3) TC-BAS, TC-SC only with deactivated telemetry function
- 4) A machine with the maximum expansion level of functions is assumed. Depending on the machine configuration, the number of possible control points and delay times in combination with the terminal may therefore change.
- 5) AUX assignment is only supported on the two joysticks of the Command Pro armrest. Assigning the pushbutton bar deletes the assignment on the job computer after a restart.

All information without guarantee. Subject to change without notice. Current lists are always available on the Internet at www.rauch.de or at www.aef-database.org